

FIG. 1B




FIG. 2A




FIG. 2A-1




FIG. 2B

"LOCAL OpenVMS SYSTEM"

"REMOTE OpenVMS SYSTEM "




FIG. 2C




FIG. 2C-1




FIG. 2D




FIG. 2D-1

Cache User
Interface Code:




FIG. 3A




FIG. 3A-1

Cache User Interface Code:

11

180

Include Maximum
Allowed Cached Disks In
Setup Information

182

Send Setup Buffer To
Driver

Cache Driver Code:

184

START SETMODE

186

CACHE Shutdown
In Progress?

YES

ERROR
EXIT

188

NO

190

CACHE
CURRENTLY
ON ?

YES

ERROR
EXIT

191

NO

192

Copy CACHE Set-up
Information Into
Characteristic Data Cells

13

FIG. 3B



Cache Driver Code:




FIG. 3C






FIG. 4A-1

Cache Driver Code




FIG. 4B




FIG. 4B-1




FIG. 4C




FIG. 4C




FIG. 4D - 1




FIG. 4E




FIG. 4E-1




FIG. 4F




FIG. 4F-1




FIG. 4G




FIG. 4G-1




FIG. 4H




FIG. 4H-1




FIG. 4H-2

Cache Driver Code:
(Intercepted Disk I/O)




FIG. 5A




FIG. 5B




FIG. 5C




FIG. 5C-1




FIG. 5D




FIG. 5E




FIG. 5F




FIG. 5F-1





FIG. 5G






FIG. 51





FIG. 5J






FIG. 5L




FIG. 5L-1




FIG. 5L-2




FIG. 5P




FIG. 5M




FIG. 5N




FIG. 50